

TOP TIPS FOR MEASURING UP FOR CURTAINS



Width

1. Measure existing track or pole width (A). If no pole, measure the window recess width (C) and add 150mm each side (B).

Drop

2. Measure from top of track or pole to where you want the curtains to finish (A). If you do not have existing curtains, measure the window recess drop (C) and add 150mm to the top and bottom of the window measurement.

Please make a note of potential obstacles such as radiator height, electrical sockets and baton width (if this exists).

Any questions, give one of our curtain guru's a call on 01249 464465, or drop an email over to sales@bridgecontractinteriors.com and they'd be happy to assist!

